SD2EX-B3

7/8-14 UNF • Q_{max} 60 l/min (16 GPM) • p_{max} 350 bar (5100 PSI)











Technical Features

- Valve and solenoid design prevents a surface temperature capable of igniting
- > Solenoid coil in acc. with directive 94/9/EC (ATEX) for explosion-hazard zones
- > Explosion protection for gas, dust, and mining; solutions for all zones
- > Solenoid with encapsulated enclosure
- Hardened precision parts
- > High flow capacity and high transmitted hydraulic power
- > All ports may be fully pressurised
- > Wide range of manual overrides available
- Coils interchangeable within Argo-Hytos ATEX/IECEx product line
- > In the standard version, the valve is zinc-coated for 520 h protection acc. to ISO 9227

Technical Data

Valve size / Cartridge cavity			7/8-14 UNF-2A / B3		
Max. flow		l/min (GPM)	60 (15.9)		
	Max. operating pressure		350 (5080)		
Fluid temperature ra		bar (PSI) °C (°F)	` '		
		1/h	-30 +70 (-22 +158)		
Max. switching freq	Max. switching frequency		15 000		
Mass with coil		kg (lbs)	1.61 (3.55)		
Technical Data - Exp	losion-proof Sole	enoid			
Voltage type			AC 50 / 60 HZ	DC	
Available voltages	Available voltages		110, 230	12, 24, 48, 110	
Available nominal power		W	10		
Supply voltage tolerance		%	AC, DC ± 10		
Duty cycle			S1 (100 % ED)		
Enclosure type acc. to EN 60529		IP 65			
Mass (solenoid only)		kg (lbs)	1.3 (2.87)		
Ambient temperatu	re range				
Temperature class / Nominal power	T4 / 10 W		-30 +70 (-22 +158)		
	T5 / 10 W	°C (°F)	-30 +55 (-22 +131)		
	T6 / 10 W		-30 +45 (-22 +113)		

		Datasheet	Туре
General information		GI_0060	Products and operating conditions
Coil types		C_8007	74 EX 18
Valve bodies	In-line mounted	SB_0018	SB-B3*
	Sandwich mounted	SB-04(06)_0028	SB-*B3*
Cavity details / Form tools		SMT_0019	SMT-B3*
Spare parts		SP_8010	


ATEX/IECEx Classification

	EPS14ATEX1744 X				
AC	€x M2 Ex mb Mb				
	⟨ Il 2G Ex mb IIB T4, T5, T6 Gb				
	⟨ Il 2D Ex mb IIIC T135°C, T100°C, T85°C Db				
	(Ex) I M2 Ex e mb I Mb				
DC	⟨Ex⟩ I 2G Ex e mb IB T4, T5, T6 Gb				
	⟨Ex⟩ 2D Ex tb C T135°C, T100°C, T85°C Db				
	IECEx EPS14.0064 X				
	Ex mb I Mb				
AC	Ex mb IIB T4, T5, T6 Gb				
	Ex mb IIIC T135°C, T100°C, T85°C Db				
	Ex e mb I Mb				
DC	Ex e mb IIB T4, T5, T6 Gb				
	Ex tb IIIC T135°C, T100°C, T85°C Db				

Characteristics measured at $v = 32 \text{ mm}^2/\text{s}$ (156 SUS)


Operating limits

Ambient temperature 70 °C (158 °F), Voltage U₂ -10 % (24 VDC), Power P₂ 10 W



	Model	Direction		Model	Direction
1	2D21	3→2	4	2D25	2→1
2	2D21	2→1	5	2D26	3→2
3	2D25	3→2	6	2D26	2→1

Pressure drop related to flow rate




	Model	Direction		Model	Direction
1	2D21	2→1	1	2D26	3→2
2	2D21	3→2	1	2D26	2→1
3	2D25	3→2	4	2D25	2→1


For operating limits under conditions other than shown contact the technical support.

Page 1 www.argo-hytos.com






Manual Override in millimeters (inches)



In case of solenoid malfunction or power failure, the spool of the valve can be shifted by manual override. For alternative manual overrides contact our technical support.


Ordering Code




www.argo-hytos.com



Solenoid Marking





Group I (Mining)

ATEX mark of conformity to the 94/9CE directive and to the applicable technical norms

Group I for mines

M2 High protection - equipment category

Ex e mb Type of protection: e - increased safety, mb - encapsulated

I Gas group (methane)

Mb Equipment protection level - high level protection for explosive atmosphere

Group II

ATEX mark of conformity to the 94/9CE directive and to the applicable technical norms II 2G Solenoid for surface plants with gas and vapors environment for zones 1 and 2

II 2D Solenoid for surface plants with dust environment for zones 21 and 22

Ex e mb Type of protection: e - increased safety, mb - encapsulated

Ex tb Type of protection: tb - protection by enclosure IIB Equipment suitable for substances (gas) of group IIB

IIIC Equipment suitable for conductive dust

T6/T4 Temperature class (maximum solenoid surface temperature)

T85/T135 Maximum solenoid surface temperature

Gb Equipment protection level - high level protection for explosive gas atmosphere
Db Equipment protection level - high level protection for explosive dust atmosphere



Initial installation

- > The ambient temperature range shall not exceed the temperatures given in chapter 2. The maximum temperature of the medium (generally hydraulic fluid) shall not exceed 70 °C (158 °F).
- > It is the user's duty to ensure free and unhindered heat emission during operation. This means that the solenoid shall neither be covered nor stored immediately adjacent to heat sources (e.g. fan heaters) during operation.
- > The solenoid shall not be subjected to direct sunlight during operation.


Installation notice - installation, mounting, demounting

- > Using the V DC type for temperature class T4 requires a cable with an operating temperature limit of at least +105 °C (221 °F), e.g. LAPP FD Robust. T5 and T6 require a cable with an operating temperature limit of at least +90 °C (194 °F). The fastening torque on the cable gland depends of the used cable and is to be determined by the installing user.
- > When installing the V DC solenoid, the fastening torque of the screws shall be [4 Nm (2.95 lbf.ft)] and for the BARTEC connection box [0.4 Nm (0.30 lbf.ft)].
- When installing the V DC solenoid, an appropriate cable shoe of size M3 with a crosssectional area of 0.75 mm² with an operating temperature limit of at least +105 °C (221 °F) is to be used.
- > The user has to safeguard each solenoid with a fuse: I_n ≤ 3xI_G, with trigger characteristic "slow blow". (I_G values see Operating Instructions Table 2). The breaking capacity of the fuse link has to be stronger than the maximum short circuit current at the user's operating area.
- > EX-secured components must be used during mounting in case the fuse and/or the interface are within the EX-range.

Safety notice - Please read carefully

- In case the solenoid shows any signs of a defect, malfunctioning or external damage (including corrosion), the device must immediately be taken out of operation.
- > Any deposits on the surface of the device shall not obstruct heat emission.
- > To maintain legibility of the data plate, the solenoid must not be coated.

Caution





- Always exchange the complete solenoid. Do not try to repair the solenoid.
 Under no circumstances shall any changes be made to the solenoid or the connecting cable.
- > Never operate the solenoid when disconnected from the valve body.
- > Demount the solenoid only in secure areas (not in EX-areas). If this is not possible, the solenoid must cool off for at least 10 minutes.

www.argo-hytos.com