



## Accessories

# Suction Strainer Set FA 016.1775

FA 014 · FA 016 · FAPC 016 · FNA 008 · FNA 016



FA 016 with screwed-in suction strainer set FA 016.1775



Suction strainer set FA 016.1775

## Description

The suction strainer set FA 016.1775 guarantees pump protection, when the existing suction strainer at the suction pipe of the oil service units FA 014, FA 016 and FAPC 016 cannot be used. This is the case, when the oil service units have to be mounted to the hydraulic unit by quick fitting coupling or ball valve, or the opening of the tank is not sufficiently dimensioned. The suction strainer set FA 016.1775 also serves as an alternative for the off-line filter units FNA 008 or FNA 016, if they are mounted to hydraulic units afterwards and installation of a suction strainer within the tank is impossible.

The suction strainer set FA 016.1775 consists of a suction strainer element 200 µm (1), a clip (2), a connection part with O-ring (3) and a connection piece (4).

## Installation of the suction strainer set

- › The suction pipe with suction strainer, mounted to the ARGO-HYTOS oil service unit, has to be removed.
- › The suction strainer set FA 016.1775 is directly screwed into the filter housing.
- › A suction pipe with DN 25 is connected (can be locked by hose clip).

The suction strainer set FA 016.1775 is designed in a way, so that the DN 25 hose connection can be rotated by 360° and thus be adapted to the position of the pipe inlet.

## Caution:

**With application of the FA 016.1775 strainer set in the version of FA 016-1160, an additional male end fitting has to be used!**

## Maintenance

The suction strainer (1) should be checked once a month with oil service units and every 12 months with off-line filter units.

- › Remove the clip (2) and pull the connection piece (4) from the housing (3).
- › Remove the suction strainer element from the connection piece and clean it with cleaning solvent.
- › Replace the suction strainer element (1), if damaged, by a new one S3.0405-02.
- › Mount cleaned or new suction strainer element (1) S3.0405-02 onto the housing and secure it with the plastic clip (2).

## Order-No.:

Suction strainer set complete:	FA 016.1775
Suction strainer element	
filter fineness 200 µm (1):	S3.0405-02